





High shear stress at the ends of the joint



Solve the problem by tapering the ends.



Or by using an adhesive with plastic yield